



THE EXTENT OF WATERPROOFING SHOULD TAKE INTO ACCOUNT THE LIKELYHOOD OF THE EXTENT OF WATER TO BE SPLASHED.  
THE ABOVE FIGURES ARE RECOMMENDATIONS OF TYPICAL SPLASH ZONES.